

PocketWizard

PocketWizard FlexTT5 - Unit 5NC000746 Connected

Model: CE - Europe
Application Version - 2 (build 100)
Loader Version - 2 (build 7)
Hardware Version - 105-103



Misc里发送模式的
设定。

Update Settings

Configuration C1

Configuration C2

Channel Misc

Trigger Modes (发送模式)

- Basic Trigger 勾选后只发送标准频道, 没有TTL频道。
 Transmitter Only 勾选后只有发送, 取消接收功能。

完成设定后按Apply Changes,
等候更新完成才退出连接。

Apply Changes Replicate Save Profile Load Profile

Advanced Mode

Help

PocketWizard Utility Context Help Win...

www.PocketWizard.com

Click on the PocketWizard logo to visit
www.PocketWizard.com

Update Tab

Update firmware or the Utility program,
or perform a Factory Reset.

Check For Updates

Looks online for new versions of the
PocketWizard Utility and new versions of
firmware for the connected radio, as well
as radios you've previously connected. A
dialog box will pop up with additional
instructions if required.

Update Firmware

Updates or re-installs the firmware in a
connected radio. If this button is grayed
out, then no radio is connected. Connect
a radio via USB to update or re-install its
firmware.

Factory Reset

Resets the connected radio to Factory
Defaults. All settings will be lost unless
you saved them.